



newline | Z Series Settings Cheat Sheet

To access settings, go to the panel home screen (select  in the left or right toolbar), then tap the  icon in the top right corner of the panel home screen.

Network	This setting allows you to update your network connections including settings for Wi-Fi, data usage and Hotspots.
Connected Devices	This setting shows which devices are connected with the panel, both physically and via Bluetooth.
Languages & Input	This setting allows you to choose your language and how you input text via keyboards (virtual, physical, etc.)
Date & Time	This setting allows you to change the date/time, including 24-hour mode and date format.
Storage	This setting shows you your device's built-in and internal storage.
Apps	This setting shows you all the apps currently installed on your panel, allows you to set default apps, allows you to change permissions and settings within each app, as well as uninstall apps.
Display & Theme	This setting allows you to change your panel's theme, wallpapers, logo, and font size.
Tool Bar	This setting allows you to make adjustments to the left and right floating toolbars, including customization and size.
Input and Output	<p>This setting allows you to choose the starting source on your panel, as well as how connected devices can affect your panel.</p> <ul style="list-style-type: none"> • Auto Source Switching: Switch to the new input sources once it is detected. • CEC Auto Power On: CEC Auto Power On allows connected devices to turn on the power of the display. • CEC Auto Power Off: CEC Auto Power Off allows the display to turn off the power of the connected devices.
Power	<p>This setting allows you to choose how to power on and off your panel, as well as how to adjust the energy saving features of the panel.</p> <ul style="list-style-type: none"> • You can set the display to auto power on/off on its own. Just toggle the switch next to "Auto Power On" or "Auto Power Off". Then tap "Power on time" or "Power off time" to select days of the week and times. • Energy Saving: Set to 30, 60, 90, or 120 minutes, Never or choose your own time. Otherwise, the display will automatically shut down after 30 minutes of no touch due to being Energy Star rated. • Motion Sensor - Turn motion sensor on/off.
Screen Eye Filters	<p>This setting allows you to make adjustments to the display mode of the panel to reduce eye strain.</p> <ul style="list-style-type: none"> • Writing Mode Filter: Change white brightness while in whiteboard mode. • Brightness Mode Filter: Change screen brightness based on ambient light. • Bluelight Filter: The filter level warms the color temperature of your screen to make it easier to read text on bright screens. This filter level adds an amber tint to the color of your screen. This makes it easier to look at your screen or read in light.
System	This setting shows you information regarding your panel, as well as allows you to make advanced changes to your panel through Admin Mode.